

PRO SERIES

INSTALLATION INSTRUCTIONS

M6 Hexagon Key



Tool Include ☐ Yes ☐ No

M8 Hexagon Key



Tool Include ☐ Yes ☐ No

M12 Hexagon Key



Tool Include ☐ Yes ☐ No

Phillips Screwdriver



Tool Include ☐ Yes ☐ No

Wrench



Tool Include ☐ Yes ☐ No

PRO SERIES

INSTALLATION INSTRUCTIONS

INDORACK
NETWORK CABINET

STEP A

1



Top Frame



2



Bottom Frame



3



Vertical Main Frame



4



M8*20 Screws (16 Pcs)
Spring Panel #8

5



Inserting the end of the
Frame into the Slots on
the Top & Bottom Frame



6



Locking with Screws



7

Lock Panel of
Front Door



Lock Panel of
Side Door



Locking the Main Frame

STEP B

1



M6*12 Screws &
M6 Nuts (16 Sets)



2



2.5" Castors &
Adjustable Feet (4 Sets Each)



3



Installing Castors
& Adjustable Feet



4



Installation Completed
Show for Main frame,
Castors & Adjustable Feet

STEP C

1



M6*12 Screws
for Top Cover (4 Pcs)



2



Top Cover



Installing Top Cover

PRO SERIES

INSTALLATION INSTRUCTIONS

INDORACK
NETWORK CABINET

STEP D

1



Mounting Angle



2



STT5*10 Self-Tapping
Screws (8 Pcs)



3



Installing Mounting Angle

STEP E

1



19" Mounting Profile



2

M6*12 Screws (32 Pcs)
M6 Square Nuts (16 Pcs)
M6 Inserting Nuts (16 Pcs)



Using for Installing
Mounting Profile

3

M6*12 Screws (4 Sets)
& M6 Nuts (4 Sets)



Mounting Profile Connecting with Mounting Angle

4

M6 Inserting Nuts (2 Pcs)
& M6*12 Screws (2 Pcs)



Mounting Profile Connecting with Bottom Frame

5

M6 Inserting Nuts (2 Pcs)
& M6*12 Screws (2 Pcs)



Mounting Profile Connecting
with Top Frame

6



Step E Completed Show

STEP F

1



Front Door



2



The Hinger Bolt inserts
into the Hole of Door Bolt



3



Step F Completed Show

PRO SERIES

INSTALLATION INSTRUCTIONS

INDORACK
NETWORK CABINET

STEP G



Rear Doors



Installing Rear Door



Step G Completed Show

STEP H



Side Doors



Installing Side Doors



Lock Fastener Locking
into The Frame

Installation Completed

